

ARC-1738-C1

Advanced Rugged Panel PC with Onboard Tiger Lake U 11th
Intel® Core™ SoC i7/i5/i3 & Celeron® BGA Processor

Quick Reference Guide

1st Ed – 17 February 2023

Copyright Notice

Copyright © 2023 Avalue Technology Inc., ALL RIGHTS RESERVED.

FCC Statement



THIS DEVICE COMPLIES WITH PART 15 FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS:

- (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE.
- (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRED OPERATION.

THIS EQUIPMENT HAS BEEN TESTED AND FOUND TO COMPLY WITH THE LIMITS FOR A CLASS "A" DIGITAL DEVICE, PURSUANT TO PART 15 OF THE FCC RULES.

THESE LIMITS ARE DESIGNED TO PROVIDE REASONABLE PROTECTION AGAINST HARMFUL INTERFERENCE WHEN THE EQUIPMENT IS OPERATED IN A COMMERCIAL ENVIRONMENT. THIS EQUIPMENT GENERATES, USES, AND CAN RADIATE RADIO FREQUENCY ENERGY AND, IF NOT INSTALLED AND USED IN ACCORDANCE WITH THE INSTRUCTION MANUAL, MAY CAUSE HARMFUL INTERFERENCE TO RADIO COMMUNICATIONS.

OPERATION OF THIS EQUIPMENT IN A RESIDENTIAL AREA IS LIKELY TO CAUSE HARMFUL INTERFERENCE IN WHICH CASE THE USER WILL BE REQUIRED TO CORRECT THE INTERFERENCE AT HIS OWN EXPENSE.

Notice

This guide is designed for experienced users to setup the system within the shortest time. For detailed information, please always refer to the electronic user's manual.

Copyright Notice

Copyright © 2023 Avalue Technology Inc., ALL RIGHTS RESERVED.

No part of this document may be reproduced, copied, translated, or transmitted in any form or by any means, electronic or mechanical, for any purpose, without the prior written permission of the original manufacturer.

Trademark Acknowledgement

Brand and product names are trademarks or registered trademarks of their respective owners.

Disclaimer

Avalue Technology Inc. reserves the right to make changes, without notice, to any product, including circuits and/or software described or contained in this manual in order to improve design and/or performance. Avalue Technology assumes no responsibility or liability for the use of the described product(s), conveys no license or title under any patent, copyright, or masks work rights to these products, and makes no representations or warranties that

these products are free from patent, copyright, or mask work right infringement, unless otherwise specified. Applications that are described in this manual are for illustration purposes only. Avalue Technology Inc. makes no representation or warranty that such application will be suitable for the specified use without further testing or modification.

Life Support Policy

Avalue Technology's PRODUCTS ARE NOT FOR USE AS CRITICAL COMPONENTS IN LIFE SUPPORT DEVICES OR SYSTEMS WITHOUT THE PRIOR WRITTEN APPROVAL OF Avalue Technology Inc.

As used herein:

1. Life support devices or systems are devices or systems which, (a) are intended for surgical implant into body, or (b) support or sustain life and whose failure to perform, when properly used in accordance with instructions for use provided in the labeling, can be reasonably expected to result in significant injury to the user.
2. A critical component is any component of a life support device or system whose failure to perform can be reasonably expected to cause the failure of the life support device or system, or to affect its safety or effectiveness.

A Message to the Customer

Avalue Customer Services

Each and every Avalue's product is built to the most exacting specifications to ensure reliable performance in the harsh and demanding conditions typical of industrial environments. Whether your new Avalue device is destined for the laboratory or the factory floor, you can be assured that your product will provide the reliability and ease of operation for which the name Avalue has come to be known.

Your satisfaction is our primary concern. Here is a guide to Avalue's customer services. To ensure you get the full benefit of our services, please follow the instructions below carefully.

Technical Support

We want you to get the maximum performance from your products. So if you run into technical difficulties, we are here to help. For the most frequently asked questions, you can easily find answers in your product documentation. These answers are normally a lot more detailed than the ones we can give over the phone. So please consult the user's manual first.

To receive the latest version of the user's manual; please visit our Web site at:

<http://www.avalue.com.tw/>

Content

1.	Getting Started	7
1.1	Safety Precautions	7
1.2	Packing List.....	7
1.3	System Specifications	8
1.4	System Overview	11
1.4.1	I/O View	11
1.5	System Dimensions	12
2.	Hardware Configuration	13
2.1.1	Serial port connector 1 (COM1).....	14
2.1.2	Serial port connector 2/3 (COM2/3).....	14
2.2	Installing Hard Disk & Memory	15
2.3	Motherboard Overviews	17
2.4	Motherboard Jumper and Connector list	18
2.5	Motherboard Jumpers & Connectors settings	20
2.5.1	Serial port 1/2 pin9 signal select (JRI1/JRI2)	20
2.5.2	LVDS Back Light power selection (JSBKL1)	20
2.5.3	AT/ATX Power Mode Select (JSATX1)	21
2.5.4	M2KB1 Voltage setting (JP1)	21
2.5.5	Clear CMOS (JBAT1)	22
2.5.6	LCD Inverter connector (JBKL1)	22
2.5.7	LCD Inverter connector (JBKL2)	23
2.5.8	LVDS connector (LVDS1).....	23
2.5.9	eDP_Panel connector (EDP1).....	24
2.5.10	General purpose I/O connector (DIO1)	24
2.5.11	Serial port1 connector (JCOM1).....	25
2.5.12	Serial port2 connector (JCOM2).....	25
2.5.13	Serial port 3/4/5/6 connector (JCOM3/4/5/6).....	26
2.5.14	Serial Port 1/2 RS485/422 Mode connector (JRS485_1/2)	26
2.5.15	SATA Power connector 1 (SPWR1).....	27
2.5.16	Power connector (PWR1).....	27
2.5.17	USB connector 3 (JUSB3).....	28
2.5.18	USB connector 4 (JUSB4).....	28
2.5.19	Speaker connector (SPK1).....	29
2.5.20	SPI connector (JSPI1)	29

2.5.21	Battery connector (BT1)	30
2.5.22	Audio connector (JFAUD1).....	30
2.5.23	EC Debug (JEC_SPI)	31
2.5.24	Miscellaneous setting connector 1 (JFPT1)	31
2.5.25	Miscellaneous setting connector 2 (FPT2)	32
2.5.26	LPC connector (JLPC1).....	32
2.5.27	CPU fan connector (CPU_FAN1).....	33
2.5.28	USIM connector (USIM2)	33
2.6	Mounting the system (ARC-1738-C1).....	34
2.6.1	Wall Mounting	34
2.6.2	Arm/ Stand Mounting	36
2.6.3	Panel Mounting.....	37
3.BIOS Setup	39	
3.1	Introduction	40
3.2	Starting Setup	40
3.3	Using Setup	41
3.4	Getting Help	42
3.5	In Case of Problems.....	42
3.6	BIOS setup.....	43
3.6.1	Main Menu	43
3.6.1.1	System Language.....	44
3.6.1.2	System Date	44
3.6.1.3	System Time.....	44
3.6.2	Advanced Menu.....	44
3.6.2.1	Connectivity Configuration	45
3.6.2.2	CPU Configuration	45
3.6.2.3	Power & Performance	46
3.6.2.3.1	CPU - Power Management Control.....	46
3.6.2.4	PCH-FW Configuration.....	47
3.6.2.4.1	Firmware Update Configuration	48
3.6.2.5	Trusted Computing.....	48
3.6.2.6	ACPI Settings	49
3.6.2.7	IT8528 Super IO Configuration	49
3.6.2.7.1	Serial Port 1 Configuration	50
3.6.2.7.2	Serial Port 2 Configuration	51
3.6.2.7.3	Serial Port 3 Configuration	51
3.6.2.7.4	Serial Port 4 Configuration	52
3.6.2.7.5	Serial Port 5 Configuration	52
3.6.2.7.6	Serial Port 6 Configuration	53
3.6.2.8	EC 8528 H/W monitor	53

ARC-1738-C1

3.6.2.9	S5 RTC Wake Settings	54
3.6.2.10	USB Configuration.....	54
3.6.2.11	Network Stack Configuration.....	55
3.6.2.12	NVMe Configuration	56
3.6.3	Chipset.....	56
3.6.3.1	System Agent (SA) Configuration	57
3.6.3.1.1	Memory Configuration.....	57
3.6.3.1.2	Graphics Configuration	58
3.6.3.1.3	VMD Configuration.....	58
3.6.3.2	PCH-IO Configuration.....	59
3.6.3.2.1	PCI Express Configuration	59
3.6.3.2.1.1	PCI Express Root Port 5(LAN2-I225/I226)	60
3.6.3.2.1.2	PCI Express Root Port 6(M.2 KeyE).....	61
3.6.3.2.1.3	PCI Express Root Port 8(M.2 KeyB).....	62
3.6.3.2.2	SATA And RST Configuration.....	63
3.6.3.2.3	HD Audio Configuration	64
3.6.3.2.4	Board & Panel Configuration.....	64
3.6.4	Security.....	66
3.6.4.1	Secure Boot menu.....	66
3.6.5	Security.....	67
3.6.6	Save and exit.....	68
3.6.6.1	Save Changes and Reset	68
3.6.6.2	Discard Changes and Reset	68
3.6.6.3	Restore Defaults.....	69
3.6.6.4	Launch EFI Shell from filesystem device	69
4. Drivers Installation.....	70	
4.1	Install Chipset Driver	71
4.2	Install VGA Driver.....	72
4.3	Install Serial IO Driver	73
4.4	Install ME Driver	74
4.5	Install Audio Driver (For Realtek ALC897 and ALC888S HD Audio).....	75
4.6	Realtek Audio Console.....	76
4.7	Install LAN Driver	77
4.8	Install RST for RAID Driver	78

1. Getting Started

1.1 Safety Precautions

Warning!



Always completely disconnect the power cord from your chassis whenever you work with the hardware. Do not make connections while the power is on. Sensitive electronic components can be damaged by sudden power surges. Only experienced electronics personnel should open the PC chassis.

Caution!



Always ground yourself to remove any static charge before touching the CPU card. Modern electronic devices are very sensitive to static electric charges. As a safety precaution, use a grounding wrist strap at all times. Place all electronic components in a static-dissipative surface or static-shielded bag when they are not in the chassis.

Risk of Explosion if Battery is replaced by an Incorrect Type.
Dispose of Used Batteries According to the Instructions.

Français:

Attention!



Débranchez le câble d'alimentation de votre châssis chaque fois que vous travaillez avec le matériel. Ne faites pas de connexion lorsque le système est allumé. Les composants électroniques sensibles peuvent être endommagés par les surtensions soudaines. Seule les personnels expérimentés de l'électronique peuvent ouvrir le châssis du PC.

Précaution!



Il faut toujours mettre à la masse pour éliminer l'électricité statique avant de toucher la carte CPU. Les appareils électroniques modernes sont très sensibles aux électricités statiques. Pour des raisons de sécurité, utilisez un bracelet électrostatique. Placez tous les composants électroniques sur une surface antistatique ou dans un sac antistatique quand ils ne sont pas dans le châssis.
Risque d'explosion si la batterie est remplacée par un type incorrect. Jetez les piles usagées selon les instructions

1.2 Packing List

- 1 x ARC-1738-C1 Panel PC
- 1 x Power Adapter
- 4 x screws for VESA
- 4 x screws for 2.5" HDD
- 4 x screws for M.2 module
- * Power Cord by option

1.3 System Specifications

Component	
Mother Board	EMX-TGLC-15-A1R (I3-1115G4, 15W) EMX-TGLC-35-A1R (I5-1135G7, 15W) EMX-TGLC-65-A1R (I7-1165G7, 15W)
CPU	Onboard Tiger Lake U 11th Intel® Core™ SoC i7/i5/i3 & Celeron® BGA Processor
CPU Cooler (Type)	Fanless
Memory	2 x 260-pin DDR4 3200 MHz SO-DIMM socket, supports up to 64GB Max (non ECC only)
Adapter	CAC-ADP-120N-02R
Speaker	2 x 5W, 8ohm
Wireless LAN	IEEE802.11 ac/a/b/g/n 2.4 GHz, 5 GHz (optional)
Bluetooth	BT5.1 (optional)
Operating System	Win10 64bit, Linux
Expansion Card	<ul style="list-style-type: none"> ● 1 x M.2 Key B+M 3042/3052/2242/2260/2280 Support 1xPCIEx1/SATA/USB3.0/USB2.0 with 1 x SIM card slot, support WWAN+GNSS * M.2 key B+M SATA share from SATA2 ● 1 x M.2 Key E 2230 support WiFi module and CNVi (1 x PCI-e x1 & USB 2.0 Signal)
Other Component	AUX-089 (SIM card expansion card)
Storage	
Solid State Drive	N/A (Reserve space for future1 x 2.5" Drive Bay design)
Other Storage Device	<ul style="list-style-type: none"> ● Default by M.2 Key B+M 3042/3052/2242/2260/2280 SSD (SATA/NVMe) * M.2 key B+M SATA share from SATA2
Panel	
LCD Panel	AUO M170ETN01.1,17" 1280*1024 250NITS
LCD Control Board	Built-in
B/L Inverter/Converter	MY-5QH185 , For M170ETN01_V10B1DB
Touch Screen	17" PCAP Touch Panel , MX170CN654A0
Touch Controller	ICI2510P.C3.P2.V1
External I/O	
Serial Port	COM1: RS232/422/485 COM2~3: RS232 COM4~6: 3 x RS232/GPIO/USB 2.0 (optional)

USB Port	3 x USB3.2 Gen2 1 x USB 3.2 Gen1 3 x USB 2.0 (optional) *1 x USB2.0 for option shared the same port with COM
Video Port	2 x DP++: 1920 x 1080@60 Hz
Audio Port	1 x Line-out, 1 x Mic-in
LAN Port	2 x RJ45 LAN port: 1 x Intel® I219LM Gigabit Ethernet PHY (LAN1) 1 x Intel® I226LM 2.5 Gigabit Ethernet (LAN2)
Wireless LAN Antenna	2 x Antenna Mounting with Dust Cover
Mechanical	
Power Type	+12~24V DC-in (Default: ATX)
Power Connector Type	1 x Mini Din 4-pin DC Jack 1 x power button
Dimension	392.7 x 325.3 x 71.65 mm
Weight	5.2 Kg
Color	Black
Fanless	Fanless
OS Support	Windows 10 64bits, Linux
Reliability	
EMI Test	CE/FCC Class B/CCC
Vibration Test	<p>Random Vibration Operation</p> <p>1 Test PSD : 0.00454G²/Hz , 1.5 Grms</p> <p>2 System condition : operation mode</p> <p>3 Test frequency : 5~500 Hz</p> <p>4 Test axis : X, Y and Z axis</p> <p>5 Test time : 30 minutes per each axis</p> <p>6 IEC60068-2-64 Test Fh</p> <p>6 Storage : mSATA</p> <p>Sine Vibration test (Non-operation)</p> <p>1 Test Acceleration : 2G</p> <p>2 Test frequency : 5~500 Hz</p> <p>3 Sweep : 1 Oct/ per one minute. (logarithmic)</p> <p>4 Test Axis : X, Y and Z axis</p> <p>5 Test time : 30 min. each axis</p> <p>6 System condition : Non-Operating mode</p> <p>7. Reference IEC 60068-2-6 Testing procedures</p>


	<p>Package Vibration Test:</p> <p>1 Test PSD : 0.026G²/Hz , 2.16 Grms</p> <p>2 Test frequency : 5~500 Hz</p> <p>3 Test axis : X, Y and Z axis</p> <p>4 Test time : 30 minutes per each axis</p> <p>5 IEC 60068-2-64 Test Fh</p>
Mechanical Shock Test	<p>1 Wave form : Half Sine wave</p> <p>2 Acceleration Rate : 10g for operation mode</p> <p>3 Duration Time : 11ms</p> <p>4 No. of shock : Z axis 300 times</p> <p>5 Test Axis : Z axis</p> <p>6 operation mode</p> <p>7 Reference IEC 60068-2-27 testing procedures</p> <p>Test Eb : Shock Test</p>
Drop Test	<p>Package drop test</p> <p>Reference ISTA 2A, Method : IEC-60068-2-32 Test:Ed</p> <p>Test Ea : Drop Test</p> <p>1 Test phase : One corner, three edges, six faces</p> <p>2 Test high : 96.5cm</p> <p>3 Package weight : 4.4 Kg</p> <p>4 Test drawing</p>
Operating Temperature	<p>0 ~ 50°C</p> <p>*Air flow=0.5 m/s</p>
Operating Humidity	40°C @ 95% Relative Humidity, Non-condensing
Storage Temperature	-20°C ~ 60°C



Note: Specifications are subject to change without notice.

1.4 System Overview


1.4.1 I/O View



Connectors

Label	Function	Note
USB 2.0(optional)	3 x USB 2.0 connector(optional)	1 x USB2.0 for option shared the same port with COM
USB 3.2	4 x USB 3.2 connector	3 x USB3.2 Gen2 1 x USB3.2 Gen1
Power Switch	Power on button	
DC-IN	DC power-in connector	mini Din 4Pin
COM1/2/3/4/5/6	Serial port connector 1/2/3/4/5/6	COM1: RS232/422/485 COM2~3: RS232 COM4~6: 3 x RS232/GPIO/USB 2.0 (optional)
DP	2 x DP connector	
LAN1/2	RJ-45 Ethernet connector 1/2	

1.5 System Dimensions



(Unit: mm)

2. Hardware Configuration





Note: If you need more information, please visit our website:

<http://www.avelue.com.tw>

2.1 ARC-1738-C1 connector mapping

2.1.1 Serial port connector 1 (COM1)





RS-232

Signal	PIN	PIN	Signal
DCD	1	6	DSR
RXD	2	7	RTS
TXD	3	8	CTS
DTR	4	9	RI
GND	5		

RS-422/485


Signal	PIN	PIN	Signal
		5	GND
422RX+	4	3	485TX+
422RX-	2	1	485TX-

2.1.2 Serial port connector 2/3 (COM2/3)




Signal	PIN	PIN	Signal
DCD	1	6	DSR
RXD	2	7	RTS
TXD	3	8	CTS
DTR	4	9	RI
GND	5		

2.2 Installing Hard Disk & Memory




- Step 1. Memory Installation:** Remove 6 screws to release the chassis cover, and remove it.
Step 2 Insert the SODIMM into the memory socket.



Step 3.1 HDD Installation: Insert the HDD into the Drive Bay and fasten 4 screws.

Step 3.2 Re-assemble your system back through previous steps to complete the installation.

2.3 Motherboard Overviews



2.4 Motherboard Jumper and Connector list

Jumpers

Label	Function	Note
JRI1/2	Serial port 1/2 pin9 signal select	3 x 2 header, pitch 2.00mm
JSBKL1	LVDS Back Light power selection	3 x 1 header, pitch 2.00mm
JSATX1	AT/ATX Power Mode Select	3 x 1 header, pitch 2.54mm
JP1	M2KB1 Voltage setting	3 x 1 header, pitch 2.00mm
JBAT1	Clear CMOS	2 x 1 wafer, pitch 2.00mm


Connectors

Label	Function	Note
FPT1	Miscellaneous setting connector 1	5 x 2 header, pitch 2.54mm
FPT2	Miscellaneous setting connector 2	5 x 2 header, pitch 2.54mm
SODIMM1/2	206-pin DDR4 SO-DIMM socket	
JFAUD1	Front Audio connector	6 x 2 header, pitch 2.00mm
JKL1/2	LCD Inverter connector	5 x 1 wafer, pitch 2.00mm
JSPI1	SPI connector	4 x 2 header, pitch 2.00mm
JEC_SPI	EC Debug	5 x 2 header, pitch 2.00mm
JCOM1	Serial Port 1 connector	5 x 2 header, pitch 2.00mm
JCOM2	Serial Port 2 connector	5 x 2 header, pitch 2.00mm
JCOM3-6	Serial Port 3-6 connector	20 x 2 header, pitch 2.00mm
JDIO1	General purpose I/O connector	10 x 2 header, pitch 2.00mm
SPK1	Speaker connector	4 x 1 wafer, pitch 2.00mm
LVDS1	LVDS Connector	20 x 2 wafer, pitch 1.25mm
EDP1	eDP_Panel connector	10 x 2 wafer, pitch 1.25mm
USB1/2	USB connector 1/2	
JUSB3/4	USB connector 3/4	5 x 2 header, pitch 2.54mm
LAN1/2	RJ-45 Ethernet 1/2	
BT1	Battery connector	2 x 1 wafer, pitch 1.25mm
M2KE1	M.2 2230 Type E Slot	
M2KB1	M.2 3042/2242/2260/2280 Type B Slot	
DP1/2	DP connector 1/2	
JRS485_1/2	Serial Port 1/2 RS485/422 Mode connector	3 x 2 header, pitch 2.00mm
JLPC	LPC connector	5 x 2 header, pitch 2.00mm


DCIN1	DC Power-in connector	
PWR1	Power connector	2 x 2 wafer, pitch 4.20mm
SATA1/2	Serial ATA connector 1/2	
SPWR1	SATA Power connector 1	4 x 1 wafer, pitch 2.54mm
USIM1	USIM card slot	
USIM2	USIM connector	10 x 1 header, pitch 0.50mm
CPU_FAN1	CPU fan connector	4 x 1 wafer, pitch 2.54mm
PCIEX4_1	PCIe x4 connector	

2.5 Motherboard Jumpers & Connectors settings


2.5.1 Serial port 1/2 pin9 signal select (JRI1/JRI2)




Ring*



+12V




+5V




* Default


2.5.2 LVDS Back Light power selection (JSBKL1)



PWM Mode*




DC Mode




* Default


2.5.3 AT/ATX Power Mode Select (JSATX1)



ATX*




AT




* Default


2.5.4 M2KB1 Voltage setting (JP1)



+3.8V




+3.3V*




* Default


2.5.5 Clear CMOS (JBAT1)



Protect*





Clear CMOS





* Default

2.5.6 LCD Inverter connector (JBKL1)





PIN	Signal
1	+12V
2	GND
3	LVDS_BKLT_EN
4	LVDS_BKLTCCTL
5	+5V

2.5.7 LCD Inverter connector (JBLK2)



PIN	Signal
1	+12V
2	GND
3	EDP2_BKL滕
4	EDP2_BKLT_CTL
5	+5V



2.5.8 LVDS connector (LVDS1)



39 1



Signal	PIN	PIN	Signal
+V5S_LVDS	2	1	+ V3.3S_LVDS
+V5S_LVDS	4	3	+ V3.3S_LVDS
NC	6	5	NC
GND	8	7	GND
LVDS_DATA0_P	10	9	LVDS_DATA1_P
LVDS_DATA0_N	12	11	LVDS_DATA1_N
GND	14	13	GND
LVDS_DATA2_P	16	15	LVDS_DATA3_P
LVDS_DATA2_N	18	17	LVDS_DATA3_N
GND	20	19	GND
LVDS_DATA4_P	22	21	LVDS_DATA5_P
LVDS_DATA4_N	24	23	LVDS_DATA5_N
GND	26	25	GND
LVDS_DATA6_P	28	27	LVDS_DATA7_P
LVDS_DATA6_N	30	29	LVDS_DATA7_N
GND	32	31	GND
LVDS_CLK1_P	34	33	LVDS_CLK2_P
LVDS_CLK1_N	36	35	LVDS_CLK2_N
GND	38	37	GND
+V12S_LVDS	40	39	+V12S_LVDS

2.5.9 eDP_Panel connector (EDP1)





Signal	PIN	PIN	Signal
GND	1	2	GND
EDP_PANEL_TXN0	3	4	EDP_PANEL_TXN3
EDP_PANEL_TXP0	5	6	EDP_PANEL_TXP3
GND	7	8	NC
EDP_PANEL_TXN1	9	10	GND
EDP_PANEL_TXP1	11	12	EDP_PANEL_AUXN
GND	13	14	EDP_PANEL_AUXP
EDP_PANEL_TXN2	15	16	GND
EDP_PANEL_TXP2	17	18	EDP_PANEL_HPD
+V35_EDP	19	20	+V35_EDP

2.5.10 General purpose I/O connector (DIO1)





Signal	PIN	PIN	Signal
DI0	1	2	DO0
DI1	3	4	DO1
DI2	5	6	DO2
DI3	7	8	DO3
DI4	9	10	DO4
DI5	11	12	DO5
DI6	13	14	DO6
DI7	15	16	DO7
SMB_SCL_S0_3P3EXT	17	18	SMB_SDA_S0_3P3EXT
GND	19	20	+5V (Max current = 0.5A)

2.5.11 Serial port1 connector (JCOM1)




Signal	PIN	PIN	Signal
COM_DCD#_1	1	2	COM_RXD_1
COM_TXD_1	3	4	COM_DTR#_1
GND	5	6	COM_DSR#_1
COM_RTS#_1	7	8	COM_CTS#_1
COM_RI#_1	9	10	NC

2.5.12 Serial port2 connector (JCOM2)



Signal	PIN	PIN	Signal
COM_DCD#_2	1	2	COM_RXD_2
COM_TXD_2	3	4	COM_DTR#_2
GND	5	6	COM_DSR#_2
COM_RTS#_2	7	8	COM_CTS#_2
COM_RI#_2	9	10	NC


2.5.13 Serial port 3/4/5/6 connector (JCOM3/4/5/6)



□	□	39
□	□	
□	□	
□	□	
□	□	
□	□	
□	□	
□	□	
□	□	
□	□	
□	□	
□	□	
□	□	
□	□	
□	□	
□	□	
□	□	
□	□	
□	□	
□	□	
□	□	
□	□	
□	□	1

Signal	PIN	PIN	Signal
NC	40	39	COM_RI#_6
COM_CTS#_6	38	37	COM_RTS#_6
COM_DSR#_6	36	35	GND
COM_DTR#_6	34	33	COM_TXD_6
COM_RXD_6	32	31	COM_DCD#_6
NC	30	29	COM_RI#_5
COM_CTS#_5	28	27	COM_RTS#_5
COM_DSR#_5	26	25	GND
COM_DTR#_5	24	23	COM_TXD_5
COM_RXD_5	22	21	COM_DCD#_5
NC	20	19	COM_RI#_4
COM_CTS#_4	18	17	COM_RTS#_4
COM_DSR#_4	16	15	GND
COM_DTR#_4	14	13	COM_TXD_4
COM_RXD_4	12	11	COM_DCD#_4
NC	10	9	COM_RI#_3
COM_CTS#_3	8	7	COM_RTS#_3
COM_DSR#_3	6	5	GND
COM_DTR#_3	4	3	COM_TXD_3
COM_RXD_3	2	1	COM_DCD#_3

2.5.14 Serial Port 1/2 RS485/422 Mode connector (JRS485_1/2)





□	□	□
□	□	□

1 5



Signal	PIN	PIN	Signal
485_422TX-	1	2	422RX-
485_422TX+	3	4	422RX+
+5V	5	6	GND

2.5.15 SATA Power connector 1 (SPWR1)





PIN	Signal
1	+V5S_SATA
2	GND
3	GND
4	+V12S_SATA

2.5.16 Power connector (PWR1)





Signal	PIN	PIN	Signal
GND	2	4	+VIN
GND	1	3	+VIN

2.5.17 USB connector 3 (JUSB3)




Signal	PIN	PIN	Signal
+V5A_USB56	1	2	+V5A_USB56
USB_DN5	3	4	USB_DN6
USB_DP5	5	6	USB_DP6
GND	7	8	GND
		10	GND

2.5.18 USB connector 4 (JUSB4)





Signal	PIN	PIN	Signal
+V5A_USB78	1	2	+V5A_USB78
USB_DN7	3	4	USB2_DN8
USB_DP7	5	6	USB2_DP8
GND	7	8	GND
		10	GND

2.5.19 Speaker connector (SPK1)




Signal	PIN
SPK_L+	1
SPK_L-	2
SPK_R+	3
SPK_R-	4

2.5.20 SPI connector (JSPI1)





Signal	PIN	PIN	Signal
+V3.3A_1.8A_SPI	1	2	GND
SPI0_CS0#	3	4	SPI0 BIOS CLK
SPI0 BIOS MISO	5	6	SPI0 BIOS MOSI
BIOS HOLD#	7	8	BIOS WP#

2.5.21 Battery connector (BT1)





PIN	Signal
1	+RTCBAT
2	GND

2.5.22 Audio connector (JFAUD1)





Signal	PIN	PIN	Signal
LINEOUT_R	1	2	LINEOUT_L
GND_AUD	3	4	GND_AUD
LINEIN_R	5	6	LINEIN_L
MICIN_R	7	8	MICIN_L
LINEOUT1_JD	9	10	LINE1-JD
MIC1_JD	11	12	GND_AUD

2.5.23 EC Debug (JEC_SPI)





Signal	PIN	PIN	Signal
+V3.3A_EC	1	2	GND
EC_FSCE#	3	4	EC_FSCK
EC_FMISO	5	6	EC_FMOSI
EC_HOLD#	7	8	NC
EC_SMCLK_DEBUG	9	10	EC_SMDAT_DEBUG

2.5.24 Miscellaneous setting connector 1 (JFPT1)





Signal	PIN	PIN	Signal
		9	NC
-PWR_BNT	8	7	-Reset
+PWR_BNT	6	5	+Reset
-PWR_LED	4	3	-HD_LED
+PWR_LED	2	1	+HD_LED

2.5.25 Miscellaneous setting connector 2 (FPT2)





Signal	PIN	PIN	Signal
		9	NC
GND	8	7	Speaker-
BLK_DN	6	5	NC
BLK_UP	4	3	NC
BLK_VR(10K)	2	1	Speaker+



2.5.26 LPC connector (JLPC1)



Signal	PIN	PIN	Signal
LPC_AD0	1	2	+3.3V
LPC_AD1	3	4	PLT_BUF_RST#
LPC_AD2	5	6	LPC_LFRAME#
LPC_AD3	7	8	CLK_24M_80
LPC_SERIRQ	9	10	GND

2.5.27 CPU fan connector (CPU_FAN1)

Signal	PIN
GND	1
+12V	2
CPU_FANIN	3
FAN_PWM0	4

2.5.28 USIM connector (USIM2)

Signal	PIN
+VCC_SIM	1
GND	2
UIM_R_RESET#	3
NC	4
GND	5
UIM_R_CLK	6
UIM_R_DATA	7
GND	8
SIM_DET	9
NC	10

2.6 Mounting the system (ARC-1738-C1)


The panel PC supports various mounting options, as listed below.

- Wall mounting
- Arm/ Stand mounting
- Panel mounting


2.6.1 Wall Mounting

To mount the panel PC onto wall, follow the instruction below (see Figure for addition reference).


1. Insert four M4 screws into the VESA holes on the panel PC and tighten them to secure the bracket to the rear panel, ensure that the thread depth of the screws on the rear panel does not exceed 4mm



2. Select the location on the wall for the wall mount plate, secure the mount plate to the wall by inserting four M5 screws into pilot holes and tightening them.



3. To mount the panel PC on the wall, align the wall mount bracket attached to the panel PC with the wall mount plate on the wall and slide the panel PC downwards to hang the bracket on the mount plate. Secure the panel PC in place by tightening screws in the wall mount bracket.



MAIN PARTS

ITEM	1	2	3
PARTS			M5X15
QTY	1	1	2

PARTS FOR TV BRACKETS

ITEM	4
PARTS	
QTY	4


PARTS FOR WALL BRACKETS

ITEM	5	6
PARTS		
QTY	4	4

2.6.2 Arm/ Stand Mounting

ARC-1738-C1 can be mounted on a VESA-compliant arm mount with a 100mm interface pad. To affix the panel PC to an arm mount, follow the steps below.


1. Refer to the installation instruction of mounting arm/ stand to correctly assembly the arm/ stand onto the surface as a base.
2. Align the retention screw holes on the mounting arm interface with VESA holes in the panel PC and secure the panel PC with four M4 retention screws. Ensure that the thread depth of the screws on the rear panel does not exceed 4mm




2.6.3 Panel Mounting

To mount the flat bezel panel PC into a panel, follow the steps below.


1. Prepare a panel cutout according to the panel PC dimensions. For ARC-1738-C1 the panel cutout dimension is 382.5 x 315.2 mm




2. Install the panel PC in the cabinet and retrieve hook brackets from the accessory box



3. Insert the hook brackets into the holes following the direction of the arrows shown in below figure and hang the panel PC



4. Tighten the screws to affix the panel PC in place, fasten all the hook bracket to ensure panel PC well fix at cabinet



3.BIOS Setup

3.1 Introduction

The BIOS setup program allows users to modify the basic system configuration. In this following chapter will describe how to access the BIOS setup program and the configuration options that may be changed.

3.2 Starting Setup

The AMI BIOS™ is immediately activated when you first power on the computer. The BIOS reads the system information contained in the NVRAM and begins the process of checking out the system and configuring it. When it finishes, the BIOS will seek an operating system on one of the disks and then launch and turn control over to the operating system.

While the BIOS is in control, the Setup program can be activated in one of two ways:

By pressing or <F2> immediately after switching the system on, or

By pressing the or <F2> key when the following message appears briefly at the left-top of the screen during the POST (Power On Self Test).

Press or <F2> to enter SETUP

If the message disappears before you respond and you still wish to enter Setup, restart the system to try again by turning it OFF then ON or pressing the "RESET" button on the system case. You may also restart by simultaneously pressing <Ctrl>, <Alt>, and <Delete> keys. If you do not press the keys at the correct time and the system does not boot, an error message will be displayed and you will again be asked to.

Press F1 to Continue, DEL to enter SETUP

3.3 Using Setup

In general, you use the arrow keys to highlight items, press <Enter> to select, use the PageUp and PageDown keys to change entries, press <F1> for help and press <Esc> to quit. The following table provides more detail about how to navigate in the Setup program using the keyboard.

Button	Description
↑↓←→	Move
Enter	Select
+/-	Value
Esc	Exit
F1	General Help
F2	Previous Values
F3	Optimized Defaults
F4	Save & Exit Setup
<K>	Scroll help area upwards
<M>	Scroll help area downwards

- **Navigating Through The Menu Bar**

Use the left and right arrow keys to choose the menu you want to be in.



Note: Some of the navigation keys differ from one screen to another.

- **To Display a Sub Menu**

Use the arrow keys to move the cursor to the sub menu you want. Then press <Enter>. A “>” pointer marks all sub menus.

3.4 Getting Help

Press F1 to pop up a small help window that describes the appropriate keys to use and the possible selections for the highlighted item. To exit the Help Window press <Esc> or <Enter> key.

3.5 In Case of Problems

If, after making and saving system changes with Setup, you discover that your computer no longer is able to boot, the AMI BIOS supports an override to the NVRAM settings which resets your system to its defaults.


The best advice is to only alter settings which you thoroughly understand. To this end, we strongly recommend that you avoid making any changes to the chipset defaults. These defaults have been carefully chosen by both BIOS Vendor and your systems manufacturer to provide the absolute maximum performance and reliability. Even a seemingly small change to the chipset setup has the potential for causing you to use the override.

3.6 BIOS setup

Once you enter the Aptio Setup Utility, the Main Menu will appear on the screen. The Main Menu allows you to select from several setup functions and exit choices. Use the arrow keys to select among the items and press <Enter> to accept and enter the sub-menu.

3.6.1 Main Menu

This section allows you to record some basic hardware configurations in your computer and set the system clock.



3.6.1.1 System Language

This option allows choosing the system default language.

3.6.1.2 System Date

Use the system date option to set the system date. Manually enter the Month, day and year.

3.6.1.3 System Time


Use the system time option to set the system time. Manually enter the hours, minutes and seconds.




Note: The BIOS setup screens shown in this chapter are for reference purposes only, and may not exactly match what you see on your screen.
Visit the Avalue website (www.alue.com.tw) to download the latest product and BIOS information.

3.6.2 Advanced Menu

This section allows you to configure your CPU and other system devices for basic operation through the following sub-menus.




3.6.2.1 Connectivity Configuration




Item	Options	Description
CNVi Mode	Disable Integrated [Default] Auto Detection	This option configures Connectivity. [Auto Detection] means that if Discrete solution is discovered it will be enabled by default. Otherwise Integrated solution (CNVi) will be enabled; [Disable Integrated] disables Integrated Solution. NOTE: When CNVi is present, the GPIO pins that are used for radio

3.6.2.2 CPU Configuration




Item	Options	Description
Intel (VMX) Virtualization Technology	Disabled Enabled[Default],	When enabled, a VMM can utilize the additional hardware capabilities provided by Vanderpool Technology.
Active Processor Cores	All[Default], 1/2/3	Number of cores to enable in each processor package.

3.6.2.3 Power & Performance




3.6.2.3.1 CPU - Power Management Control




Item	Options	Description
Intel(R) SpeedStep(tm)	Disabled Enabled[Default],	Allows more than two frequency ranges to be supported.
Intel(R) Speed Shift Technology	Disabled Enabled[Default],	Enable/Disable Intel(R) Speed Shift Technology support. Enabling will expose the CPPC v2 interface to allow for hardware controlled P-states.
Turbo Mode	Disabled Enabled[Default],	Enable/Disable processor Turbo Mode (requires EMTTM enabled too). AUTO means enabled.
C states	Disabled Enabled[Default],	Enable/Disable CPU Power Management. Allows CPU to go to C states when it's not 100% utilized.
Enhanced C-states	Disabled Enabled[Default],	Enable/Disable C1E. When enabled, CPU will switch to minimum speed when all cores enter C-State.

3.6.2.4 PCH-FW Configuration



3.6.2.4.1 Firmware Update Configuration




Item	Options	Description
Me FW Image Re-Flash	Disabled[Default], Enabled	Enable/Disable Me FW Image Re-Flash function.

3.6.2.5 Trusted Computing



Item	Options	Description
Security Device Support	Disabled Enabled[Default],	Enables or Disables BIOS support for security device. O.S. will not show Security Device. TCG EFI protocol and INT1A interface will not be available.


3.6.2.6 ACPI Settings



Item	Options	Description
Enable Hibernation	Disabled Enabled[Default],	Enables or Disables System ability to Hibernate (OS/S4 Sleep State). This option may not be effective with some Operating Systems.
ACPI Sleep State	Suspend Disabled, S3 (Suspend to RAM)[Default]	Select the highest ACPI sleep state the system will enter when the SUSPEND button is pressed.

3.6.2.7 IT8528 Super IO Configuration

You can use this item to set up or change the IT8528 Super IO configuration for serial ports. Please refer to 3.6.2.7.1~ 3.6.2.7.6 for more information.




Item	Description
Serial Port 1 Configuration	Set Parameters of Serial Port 1 (COMA).
Serial Port 2 Configuration	Set Parameters of Serial Port 2 (COMB).
Serial Port 3 Configuration	Set Parameters of Serial Port 3 (COMC).
Serial Port 4 Configuration	Set Parameters of Serial Port 4 (COMD).
Serial Port 5 Configuration	Set Parameters of Serial Port 5 (COME).
Serial Port 6 Configuration	Set Parameters of Serial Port 6 (COMF).

3.6.2.7.1 Serial Port 1 Configuration



Item	Option	Description
Serial Port	Disabled Enabled [Default] ,	Enable or Disable Serial Port (COM).
UART 232 422 485	UART 232 [Default] , UART 422, UART 485	Change the Serial Port as RS232/422/485.

3.6.2.7.2 Serial Port 2 Configuration




Version 2.21.1278 Copyright (C) 2023 AMI

Item	Option	Description
Serial Port	Disabled Enabled [Default] ,	Enable or Disable Serial Port (COM).
UART 232 422 485	UART 232 [Default] , UART 422, UART 485	Change the Serial Port as RS232/422/485.

*The following setting are from MB EMX-TGLC, the ARC-1738-C1 has been set as COM1: RS232/422/485 & COM2~3: RS232 by cable.

If COM1/COM2 want to change as setting, please contact with Avalue.


3.6.2.7.3 Serial Port 3 Configuration



Version 2.21.1278 Copyright (C) 2023 AMI


Item	Option	Description
Serial Port	Disabled Enabled [Default] ,	Enable or Disable Serial Port (COM).

3.6.2.7.4 Serial Port 4 Configuration




Item	Option	Description
Serial Port	Disabled Enabled [Default] ,	Enable or Disable Serial Port (COM).

3.6.2.7.5 Serial Port 5 Configuration




Item	Option	Description
Serial Port	Disabled Enabled [Default] ,	Enable or Disable Serial Port (COM).

3.6.2.7.6 Serial Port 6 Configuration



Item	Option	Description
Serial Port	Disabled Enabled [Default] ,	Enable or Disable Serial Port (COM).

3.6.2.8 EC 8528 H/W monitor




3.6.2.9 S5 RTC Wake Settings



Item	Options	Description
Wake system from S5	Disabled [Default] , Fixed Time Dynamic Time	Enable or disable System wake on alarm event. Select FixedTime, system will wake on the hr::min::sec specified. Select DynamicTime, System will wake on the current time + Increase minutes(s).

3.6.2.10 USB Configuration

The USB Configuration menu helps read USB information and configures USB settings.




Item	Option	Description
USB transfer time-out	1 sec 5 sec 10 sec 20 sec[Default]	The time-out value for Control, Bulk, and Interrupt transfers.
Device reset time-out	10 sec 20 sec[Default] 30 sec 40 sec	USB mass storage device Start Unit command time-out.
Device power-up delay	Auto [Default] Manual	Maximum time the device will take before it properly reports itself to the Host Controller. ‘Auto’ uses default value: for a Root port it is 100ms, for a Hub port the delay is taken from Hub descriptor.
Mass Storage Devices	Auto [Default] Floppy Forced FDD Hard Disk CD-ROM	Mass storage device emulation type. ‘AUTO’ enumerates devices according to their media format. Optical drives are emulated as ‘CDROM’, drives with no media will be emulated according to a drive type.

3.6.2.11 Network Stack Configuration



Item	Option	Description
Network Stack	Enabled Disabled[Default]	Enable/Disable UEFI Network Stack.


3.6.2.12 NVMe Configuration



3.6.3 Chipset




3.6.3.1 System Agent (SA) Configuration



Item	Option	Description
VT-d	Disabled Enabled [Default]	VT-d capability.

3.6.3.1.1 Memory Configuration




3.6.3.1.2 Graphics Configuration



Item	Option	Description
Primary Display	Auto [Default] IGFX	Select which of IGFX/PEG/PCI Graphics device should be Primary Display Or select HG for Hybrid Gfx.

3.6.3.1.3 VMD Configuration




Item	Option	Description
Enable VMD controller	Disabled [Default] Enabled	Enable/Disable to VMD controller

3.6.3.2 PCH-IO Configuration



Item	Option	Description
PCH LAN Controller	Enabled [Default] Disabled	Enable/Disable onboard NIC.

3.6.3.2.1 PCI Express Configuration




3.6.3.2.1.1 PCI Express Root Port 5(LAN2-I225/I226)



Item	Option	Description
PCI Express Root Port 5 (LAN2-I225/I226)	Disabled Enabled [Default] ,	Control the PCI Express Root Port.
ASPM	Disabled [Default] L0s L1 L0sL1 Auto	Set the ASPM Level: Force L0s – Force all links to L0s State AUTO – BIOS auto configure DISABLE – Disables ASPM.
L1 Substates	Disabled L1.1 L1.1 & L1.2 [Default] ,	PCI Express L1 Substates settings.
PCIe Speed	Auto [Default] Gen1 Gen2 Gen3	Select PCIe speed.

3.6.3.2.1.2 PCI Express Root Port 6(M.2 KeyE)




Item	Option	Description
PCI Express Root Port 6 (M.2 KeyE)	Disabled Enabled [Default] ,	Control the PCI Express Root Port.
ASPM	Disabled [Default] L0s L1 L0sL1 Auto	Set the ASPM Level: Force L0s – Force all links to L0s State AUTO – BIOS auto configure DISABLE – Disables ASPM.
L1 Substates	Disabled L1.1 L1.1 & L1.2 [Default] ,	PCI Express L1 Substates settings.
PCIe Speed	Auto [Default] Gen1 Gen2 Gen3	Select PCIe speed.

3.6.3.2.1.3 PCI Express Root Port 8(M.2 KeyB)




Item	Option	Description
PCI Express Root Port 8 (M.2 KeyB)	Disabled Enabled [Default] ,	Control the PCI Express Root Port.
ASPM	Disabled [Default] L0s L1 L0sL1 Auto	Set the ASPM Level: Force L0s – Force all links to L0s State AUTO – BIOS auto configure DISABLE – Disables ASPM.
L1 Substates	Disabled L1.1 L1.1 & L1.2 [Default] ,	PCI Express L1 Substates settings.
PCIe Speed	Auto [Default] Gen1 Gen2 Gen3	Select PCIe speed.

3.6.3.2.2 SATA And RST Configuration




Item	Option	Description
SATA Controller(s)	Disabled Enabled [Default] ,	Enable/Disable SATA Device.
Port 0	Disabled Enabled [Default] ,	Enable or Disable SATA Port
SATA Port 0 DevSlp	Disabled Enabled [Default] ,	Enable/Disable SATA Port 0 DevSlp. For DevSlp to work, both hard drive and SATA port need to support DevSlp function, otherwise an unexpected behavior might happen. Please check board design before enabling it.
Port 1	Disabled Enabled [Default] ,	Enable or Disable SATA Port
SATA Port 1 DevSlp	Disabled Enabled [Default] ,	Enable/Disable SATA Port 1 DevSlp. For DevSlp to work, both hard drive and SATA port need to support DevSlp function, otherwise an unexpected behavior might happen. Please check board design before enabling it.

3.6.3.2.3 HD Audio Configuration




Item	Option	Description
HD Audio	Disabled Enabled [Default] ,	Control Detection of the HD-Audio device. Disable = HDA will be unconditionally disabled Enabled = HDA will be unconditionally enabled.

3.6.3.2.4 Board & Panel Configuration



Item	Option	Description
Active Panel	Disabled Enabled[Default]	Active Internal LVDS(eDP->Ch7511-to-LVDS) [Enabled] load vbt with EDP(7511) [Disabled] load vbt without EDP(7511)
ErP Function	Disabled[Default], Enabled	ErP Function (Deep S5).
PWR-On After PWR-Fail	Off[Default], On Last State	AC loss resume.
Wake Up by Ring	Disabled Enabled[Default],	Wake Up by Ring from S3/S4/S5
Watch Dog	Disabled[Default], 30 sec 40 sec 50 sec 1 min 2 min 10 min 30 min	Select WatchDog.
USB Standby Power	Disabled Enabled[Default],	Enabled/Disabled USB Standby Power during S3/S4/S5
Amplifier Gain	2W[Default], 6W	Amplifier Gain
M.2 KeyB P38 Setting	Low[Default], High	Set M.2 KeyB Pin38(DEVSLP) as Low/High
SHOW DMI INFO	Disabled[Default], Enabled	SHOW DMI INFO

3.6.4 Security



● Administrator Password

Set setup Administrator Password

● User Password


Set User Password

3.6.4.1 Secure Boot menu





Item	Option	Description
Secure Boot	Disabled Enabled [Default]	Secure Boot feature is Active if Secure Boot is Enabled, Platform Key(PK) is enrolled and the System is in User mode. The mode change requires platform reset
Secure Boot Mode	Standard [Default] Custom	Secure Boot mode options: Standard or Custom. In Custom mode, Secure Boot Policy variables can be configured by a physically present user without full authentication

3.6.5 Security



Item	Option	Description
Setup Prompt Timeout	1	Number of seconds to wait for setup activation key. 65535(0xFFFF) means indefinite waiting.
Bootup NumLock State	On [Default] Off	Select the Keyboard NumLock state
Quiet Boot	Disabled [Default] Enabled	Enables or disables Quiet Boot option
Boot Option #1	Set the system boot order.	
Boot Option #2	Set the system boot order.	

3.6.6 Save and exit



3.6.6.1 Save Changes and Reset

Reset the system after saving the changes.

3.6.6.2 Discard Changes and Reset

Reset system setup without saving any changes.

3.6.6.3 *Restore Defaults*

Restore/Load Default values for all the setup options.

3.6.6.4 *Launch EFI Shell from filesystem device*

Attempts to Launch EFI Shell application (Shell.efi) from one of the available filesystem devices.

4. Drivers Installation



Note: Installation procedures and screen shots in this section are for your reference and may not be exactly the same as shown on your screen.

4.1 Install Chipset Driver

All drivers can be found on the Avalue Official Website:


<http://www.avalue.com.tw>




Note: The installation procedures and screen shots in this section are based on Windows 10 operation system. If the warning message appears while the installation process, click Continue to go on.



Step 3. Click Install.



Step1. Click Next.



Step 2. Click Accept.

Step 4. Complete setup.


4.2 Install VGA Driver

All drivers can be found on the Avalue Official Website:

<http://www.alue.com.tw>.




Note: The installation procedures and screen shots in this section are based on Windows 10 operation system. If the warning message appears while the installation process, click Continue to go on.




Step 3. Click Start.



Step 1. Click Begin installation.



Step 4. Click Reboot now.



Step 2.


Click **Next** to accept license agreement.

4.3 Install Serial IO Driver


All drivers can be found on the Avalue Official Website:
<http://www.alue.com.tw>.




Note: The installation procedures and screen shots in this section are based on Windows 10 operation system. If the warning message appears while the installation process, click Continue to go on.




Step 3. Click Next.




Step 1. Click Next to continue setup.



Step 4. Click Next.



Step 2. Click Next.



Step 5. Click Finish to complete the setup.


4.4 Install ME Driver

All drivers can be found on the Avalue Official Website:


<http://www.alue.com.tw>.




Note: The installation procedures and screen shots in this section are based on Windows 10 operation system. If the warning message appears while the installation process, click Continue to go on.



Step 3. Click Next.



Step 1. Click Next to continue setup.



Step 4. Click Finish to complete setup.




Step 2. Click Next.

4.5 Install Audio Driver (For Realtek ALC897 and ALC888S HD Audio)


All drivers can be found on the Avalue Official Website:
<http://www.alue.com.tw>.



Note: The installation procedures and screen shots in this section are based on Windows 10 operation system. If the warning message appears while the installation process, click Continue to go on.



Step1. Click **Next** to Install.



Step 2. Click **Finish** to complete setup.

4.6 Realtek Audio Console


All drivers can be found on the Avalue

Official Website:

<http://www.alue.com.tw>.




Note: The installation procedures and screen shots in this section are based on Windows 10 operation system. If the warning message appears while the installation process, click Continue to go on.




A screenshot of an Administrator Command Prompt window. The command entered is: `C:\>cd C:\Users\EMX-TGLC_RAID0\Desktop\EMX-TGLC\Realtek_Audio_UI_Win10_64_1.38.277.0\RtkUWP_1.38.277.0_x64_bundle_ReleaseSign.appxupload_Windows10`. The window title is "Administrator: Command Prompt".

Step1.



A screenshot of an Administrator Command Prompt window titled "Administrator: Command Prompt - DISM_INSTALL_RtkUWP_V3.bat". The command entered is: `C:\Users\EMX-TGLC_RAID0\Desktop\EMX-TGLC\Realtek_Audio_UI_Win10_64_1.38.277.0\RtkUWP_1.38.277.0_x64_bundle_ReleaseSign.appxupload_Windows10>DISM_INSTALL_RtkUWP_V3.bat`. The window displays deployment information and a success message: "The operation completed successfully. Press any key to continue . . ." The title bar also shows the path: "C:\Users\EMX-TGLC_RAID0\Desktop\EMX-TGLC\Realtek_Audio_UI_Win10_64_1.38.277.0\RtkUWP_1.38.277.0_x64_bundle_ReleaseSign.appxupload_Windows10>DISM_INSTALL_RtkUWP_V3.bat".

Step 3.



A screenshot of an Administrator Command Prompt window. The command entered is: `C:\Users\EMX-TGLC_RAID0\Desktop\EMX-TGLC\Realtek_Audio_UI_Win10_64_1.38.277.0\RtkUWP_1.38.277.0_x64_bundle_ReleaseSign.appxupload_Windows10>DISM_INSTALL_RtkUWP_V3.bat`. The window title is "Administrator: Command Prompt".

Step 2.

4.7 Install LAN Driver


All drivers can be found on the Avalue

Official Website:


<http://www.alue.com.tw>.



Note: The installation procedures and screen shots in this section are based on Windows 10 operation system. If the warning message appears while the installation process, click Continue to go on.



Step 1. Click **OK**.



Step 2. Click **Close**.

4.8 Install RST for RAID Driver

All drivers can be found on the Avalue Official Website:
<http://www.avalue.com.tw>.



Note: The installation procedures and screen shots in this section are based on Windows 10 operation system. If the warning message appears while the installation process, click Continue to go on.

The screenshot shows the 'Important Note' step of the Intel Rapid Storage Technology setup. It includes a note about the driver's function, copyright information, and navigation buttons for back, next, and cancel.

Step 3. Click Next.

The screenshot shows the 'Welcome!' step of the setup wizard. It lists the products being installed (Intel® Rapid Storage Technology driver and Intel® Optane™ Memory and Storage Management application), recommends exiting programs before continuing, and provides copyright and navigation information.

Step 1. Click Next to continue installation.

The screenshot shows the 'Include: Intel® Optane™ Memory and Storage Management app' step. It includes a checked checkbox for including the app, a note about manual installation if not automatic, copyright information, and navigation buttons.

Step 4. Click Next.

The screenshot shows the 'License agreement:' step. It displays the INTEL SOFTWARE LICENSE AGREEMENT (OEM / IHV / ISV Distribution & Single User) and the 'IMPORTANT - READ BEFORE COPYING, INSTALLING OR USING.' section. It also shows the 'I accept the terms in the License Agreement' checkbox, copyright information, and navigation buttons.

Step 2. Click Next.

The screenshot shows the 'Restart now.' step. It indicates successful installation and the requirement to restart the PC. It includes copyright information and a 'Restart' button.

Step 5. Complete setup.

