## **CAXA0-DC**

**Desktop Cradle** 

## **Quick Reference Guide**

2<sup>nd</sup> Ed - 26 March 2021

### **Copyright Notice**

Copyright © 2021 Avalue Technology Inc., ALL RIGHTS RESERVED.

#### **FCC Statement**



THIS DEVICE COMPLIES WITH PART 15 FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS:

- (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE.
- (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRED OPERATION.

THIS EQUIPMENT HAS BEEN TESTED AND FOUND TO COMPLY WITH THE LIMITS FOR A CLASS "A" DIGITAL DEVICE, PURSUANT TO PART 15 OF THE FCC RULES.

THESE LIMITS ARE DESIGNED TO PROVIDE REASONABLE PROTECTION AGAINST HARMFUL INTERFERENCE WHEN THE EQUIPMENT IS OPERATED IN A COMMERCIAL ENVIRONMENT. THIS EQUIPMENT GENERATES, USES, AND CAN RADIATE RADIO FREQUENCY ENERGY AND, IF NOT INSTATLLED AND USED IN ACCORDANCE WITH THE INSTRUCTION MANUAL, MAY CAUSE HARMFUL INTERFERENCE TO RADIO COMMUNICATIONS.

OPERATION OF THIS EQUIPMENT IN A RESIDENTIAL AREA IS LIKELY TO CAUSE HARMFUL INTERFERENCE IN WHICH CASE THE USER WILL BE REQUIRED TO CORRECT THE INTERFERENCE AT HIS OWN EXPENSE.

#### A Message to the Customer

#### **Avalue Customer Services**

Each and every Avalue's product is built to the most exacting specifications to ensure reliable performance in the harsh and demanding conditions typical of industrial environments. Whether your new Avalue device is destined for the laboratory or the factory floor, you can be assured that your product will provide the reliability and ease of operation for which the name Avalue has come to be known.

Your satisfaction is our primary concern. Here is a guide to Avalue's customer services. To ensure you get the full benefit of our services, please follow the instructions below carefully.

#### **Technical Support**

We want you to get the maximum performance from your products. So if you run into technical difficulties, we are here to help. For the most frequently asked questions, you can easily find answers in your product documentation. These answers are normally a lot more detailed than the ones we can give over the phone. So please consult the user's manual first.

To receive the latest version of the user's manual; please visit our Web site at: http://www.avalue.com.tw/

## Content

1.	Getting Started	4
	Safety Precautions	
	Packing List	
	System Specifications	
1.4	System Overview	
	1.4.1 Bottom View	8
	System Dimensions	
2.	Hardware Configuration	11
21	Installing Table Top Docking Station	12

## 1. Getting Started

#### 1.1 Safety Precautions

#### Warning!



Always completely disconnect the power cord from your chassis whenever you work with the hardware. Do not make connections while the power is on. Sensitive electronic components can be damaged by sudden power surges. Only experienced electronics personnel should open the PC chassis.

#### Caution!



Always ground yourself to remove any static charge before touching the CPU card. Modern electronic devices are very sensitive to static electric charges. As a safety precaution, use a grounding wrist strap at all times. Place all electronic components in a static-dissipative surface or static-shielded bag when they are not in the chassis.

#### 1.2 Packing List

- 1 x CAXA0-DC CAXA0 Desktop Cradle
- 1 x Screw
- 1 x Power lock bracket



If any of the above items is damaged or missing, contact your retailer.

## 1.3 System Specifications

Component			
	CAXA0-DC I/O board		
Board	(Same as CAXA0-WM(wall mount kit) board)		
040	CAXA0-DC DB-A daughter board		
Other Component	(POGO connector board, Same as CAXA0-WM(wall mount kit) board)		
External I/O			
USB Port	3 x USB 2.0		
	1 x 10/100 Mbit/s RJ45 LAN (Realtek RTL8153B)		
LAN Port	Standard: IEEE 802.3 10BASE-T and 100Base-TX, auto-negotiation, full and		
	half-duplex		
	Isolation: Basic insulation (reference voltage: 250V; test voltage: 1500V)		
Power input	19V DC in		
Indicator Light	link indicator LED (LED light up when tablet connected to the Desktop cradle)		
Mechanical			
Power Type	+19V DC-In		
Power Connector	DC-Jack		
Туре	DO GUER		
Dimension	180 x 129.2 x 198.2 mm(L x W x H)		
Weight	1.05 Kg		
Color	Black		
Fanless	Fanless		
Other	IPX1		
Reliability			
EMI Test	CE, IEC/EN60601-1-2		
Lim 100t	CE, FCC Part 15 Class B		
Safety	CE / FCC / VCCI / CCC		
Curety	IEC/EN60601-1		
	Random Vibration Operation		
	1 Test PSD : 0.00454G <sup>2</sup> /Hz , 1.5 Grms		
	2 System condition : operation mode		
	3 Test frequency : 5~500 Hz		
Vibration Test	4 Test axis : X,Y and Z axis		
	5 Test time : 30 minutes per each axis		
	6 IEC60068-2-64 Test Fh		
	7 Storage : mSATA		

#### CAXA0-DC

	Sine Vibration test (Non-operation)
	1 Test Acceleration : 2G
	2 Test frequency : 5~500 Hz
	3 Sweep: 1 Oct/ per one minute. (logarithmic)
	4 Test Axis: X,Y and Z axis
	5 Test time :30 min. each axis
	6 System condition : Non-Operating mode
	7. Reference IEC 60068-2-6 Testing procedures
	Package Vibration Test:
	1 Test PSD : 0.026G²/Hz , 2.16 Grms
	2 Test frequency : 5~500 Hz
	3 Test axis : X,Y and Z axis
	4 Test time : 30 minutes per each axis
	5 IEC 60068-2-64 Test Fh
	1 Wave from : Half Sine wave
	2 Acceleration Rate : 10g for operation mode
	3 Duration Time : 11ms
Mechanical Shock	4 No. of shock : Z axis 300 times
Test	5 Test Axis : Z axis
	6 operation mode
	7 Reference IEC 60068-2-27 testing procedures
	Test Eb : Shock Test
	Package drop test
	Reference ISTA 2A, Method : IEC-60068-2-32 Test:Ed
	Test Ea : Drop Test
Drop Test	1 Test phase : One corner, three edges, six faces
	2 Test high: 96.5cm
	3 Package weight : 1Kg
	4 Test drawing
Operating	0°C to 40°C (32°F to 104°F) work with tablet
Temperature	5 5 15 15 (62 1 to 15 1 ) Horiz Mari (ablot)
Operating	15%~95% Relative Humidity, Non-Condensing
Humidity	
Storage	-20°C to 60°C (-4°F to 140°F)
Temperature	
Other Test	In house ESD testing 8KV contact and 15KV Air Criteria B


#### **Quick Reference Guide**



**Note:** Specifications are subject to change without notice.


#### 1.4 System Overview

#### 1.4.1 **Bottom View**




Connectors					
Label	Function	Note			
DC-IN	DC Power-in connector				
LAN	RJ-45 Ethernet connector				
USB	3 x USB2.0 connector				

## 1.5 System Dimensions



(Unit: mm)

#### CAXA0-DC



(Unit: mm)


# 2. Hardware Configuration



Note: If you need more information, please visit our website:

http://www.avalue.com.tw

### 2.1 Installing Table Top Docking Station



**Step 1.** Slide the tablet into the table top docking station.

